5 Simplex

True Alarm® Addressable Fire Alarm Control Panels

UL, ULC, CSFM Listed; FM Approved; MEA (NYC) Acceptance*

4008 Fire Alarm Control Panel for IDNet™ Addressable Devices and TrueAlarm Addressable Smoke Detection

Features

Control panel operator convenience features:

- Wide viewing angle 2 x 20 (40 character) alphanumeric LCD and dedicated LEDs provide convenient panel status information
- Operation is programmable using a multi-function keypad and the panel LCD or via service computer (PC)
- RS-232 service port provides upload/download PC access for panel configuration and event history logs
- Software updates are via PC download
- Convenient library of standard custom label terms
- Standard on-board DACT provides: Contact ID, 3/1, 4/2, BFSK, and SIA formats
- WALKTESTTM silent or audible system test**
- Voltage and current for both the battery charger and the battery can be displayed at the front panel LCD

Addressable Devices:

 Using IDNet communications, up to 200 addressable TrueAlarm detection points or addressable device points are available (see page 3 for details)**

Two Standard Notification Appliance Circuits (NACs):

- Class A or Class B outputs with solid state overcurrent protection per NAC, each rated for 2 A
- Selectable for Simplex® SmartSyncTM two-wire horn/strobe control or synchronized strobe control**

Standard Power Supply:


- Provides 3 A maximum @ nominal 24 DC
- Automatic input power selection operates with 120 VAC or 240 VAC, 50 or 60 Hz
- On-board temperature compensated battery charger for up to 12.7 Ah batteries in cabinet (UL and ULC) and up to 25 Ah batteries in separate cabinet (UL only)

Additional standard features:


- Programmable Active Status Reminder
- Two auxiliary relays
- NACs, Relay outputs, and communications circuits are power limited (AC input, battery circuits, and City Circuit Module outputs are non-power limited)
- Available with red or beige cabinet
- UL listed to Standard 864

Available option modules:

- Door mounted 24 LED annunciator (standard on ULC models)
- 3 A Expansion Power Supply with two on-board 2 A NACs that operate the same as standard NACs
- City Interface Module and Auxiliary Relay Module
- Remote LCD and LED/Switch Annunciators



4008-9101 Standard Control Panel



4008-9121 Control Panel with 24 LED Annunciator (required for ULC applications)

Description

For areas requiring up to 200 addressable input devices and up to 4 NACs, the Simplex 4008 Series fire alarm control panels provide flexible initiating circuit monitoring, extensive programmable control capability, and LCD annunciated circuit-specific 20 character custom labels.

- * See page 2 for additional ULC and MEA information. This product has been approved by the California State Fire Marshal (CSFM) pursuant to Section 13144.1 of the California Health and Safety Code. See CSFM Listing 7165-0026:318 for allowable values and/or conditions concerning material presented in this document. It is subject to re-examination, revision, and possible cancellation. Additional listings may be applicable, contact your local Simplex® product supplier for the latest status. Listings and approvals under Simplex Time Recorder Co. are the property of Tyco Safety Products Westminster.
- ** TrueAlarm analog smoke detection is protected by one or more of the following U.S. Patents: 5,155,468; 5,173,683; 5,543,777. IDNet addressable communications are protected by U.S. Patent No. 4,796,025. IDNet duplicate device detection is protected under U.S. Patent No. 6,034,601. WALKTEST system test is protected under U.S. Patent No. 4,725,818. SmartSync horn/strobe operation is protected under U.S. Patent No. 6,281,789. Two-wire synchronization circuit operation is protected by U.S. patent No. 5,559,492.

Standard Feature Details

Addressable operation is provided by an IDNet signaling line circuit (SLC) capable of communicating to up to 200 addressable devices (points). Addressable devices include: TrueAlarm smoke detection, heat detection, and duct detection; supervised addressable modules for single and multiple contact monitoring, manual stations, isolation modules, and a remote signal module (see list on page 4.) (Please note that this panel provides a limited TrueAlarm operation feature set. For larger applications that require the full complement of TrueAlarm features, contact your local Simplex product supplier.)

Two, 2 A On-Board NACs provide conventional reverse polarity operation, selectable as Class A or Class B, with electronic control and overcurrent protection. Operation is selectable for synchronized strobe or SmartSyncTM horn/strobe two wire operation. Horn control can be selected at the panel for: Temporal pattern coding, Steady On, Slow March Time of 20 beats per minute (BPM), or Fast March Time of 120 BPM. **Note:** When selected for SmartSync horn/strobe control, March Time produces 60 BPM.

The 24 VDC Auxiliary output provides up to 500 mA for system use. (Auxiliary output current is counted for total power supply capacity.)

Standard Auxiliary Relay Outputs. Two relay outputs are available, selectable as normally open or normally closed, rated 2 A @ 30 VDC per below:

Aux Relay 1 is normally assigned to General Alarm operation but is programmable (see page 7)

Aux Relay 2 (Trouble) is energized when Normal and is de-energized with a Trouble condition.

Standard Feature Details (Continued)

On-Board Dual Line DACT. Operation can be selected for Contact ID, SIA, 3/1, 4/2, and BFSK formats. Reporting includes Alarm, Supervisory, Trouble, and AC Failure. Operation includes automatic 24 hour test and programmable power fail report delay.

Power Supply and Battery Charger. DC power output is 3 A @ 24 VDC for panel use. The temperature compensated battery charger (sealed lead-acid batteries only) is rated for up to 25 Ah batteries per UL 864 and up to 12.7 Ah per ULC-S527. (Up to 12.7 Ah batteries fit in the cabinet, larger batteries require an external cabinet.) Panel electronics can measure and display voltage and current for the power supply, batteries and the battery charger (standard and expansion power supply). Depleted battery trouble is monitored and annunciated and depleted battery cutout can be selected. Active battery status monitor supervises charger operation.

Optional Feature Details

Expansion Power Supply. Provides 3 A total @ 24 VDC, two additional 2 A NACs, and an additional auxiliary power output of 500 mA. Output operation is the same as on the standard power supply.

Expansion Relay Module. Provides three relays, one each for Alarm, Supervisory, and Trouble conditions. Each is jumper selectable as N.O. or N.C. Contacts are rated 2 A @ 30 VDC. Location is the same as for the City Circuit Modules.

City Circuit Modules. These modules are available with or without on-board disconnect switches, depending on local requirements (either type can be disconnected through the front panel under password control). Connections are for Remote Station (reverse polarity) or Municipal Master (local energy). Reporting includes Alarm, Supervisory, and Trouble.

Product Selection

Control Panel

Model	Color	Description	Box Depth	Listi	ings	Standard Feature Summary
4008-9101	Red	Standard fire alarm control panel	4-1/4"	MEA		SLC with 200 addressable points,
4008-9102	Beige	Standard life alarm control parier	(108 mm)		II ⊢\// <i>X</i> . ∣	2 Class B/Class A NACs, 3 A power
4008-9121	Red	Fire alarm control panel with	4-5/8"	ULC		supply with battery charger; on-board DACT; for input voltage of
4008-9122	Beige	24 LED Annunciator on front door	(117 mm)	OLC		120/240 VAC, 50/60 Hz (autoselect)

Option Modules

Model	Description	
4008-9801	Expansion Power Supply; 3 A, with 2 NACs, 120/240 VAC, 50/60 Hz	Select one if required
4008-9802	Expansion Relay Module; 3 relays selectable as either N.O. or N. C.	
4006-9805*	City Circuit Modules with disconnect switch	Select one if required
4006-9806*	City Circuit Modules without disconnect switch	

^{*} These City Circuit modules are also used on the 4006 Series control panels.

Accessories

Model	Description
2975-9812	Red semi-flush trim kit; 1-7/16" (37 mm) wide; includes four corners and trim pieces for top, bottom, and sides
2975-9811	Beige semi-flush trim kit; 1-7/16" (37 mm) wide; includes four corners and trim pieces for top, bottom, and sides
4009-9801	Beige External Battery Cabinet for up to 25 Ah batteries; mounts close-nippled to control panel cabinet; dimensions = 16-1/4" W x 13-1/2" H x 5-3/4" D (413 mm x 343 mm x 146 mm) [depth increased for 25 Ah effective 7/2005]

Batteries, 12 Volt (select one battery model per system standby requirements; order quantity of two)

Model	Size	Model	Size	Location	Model	Size	Location
2081-9272	6.2 Ah	2081-9288	12.7 Ah	For cabinet mount	2081-9275	18 Ah	Requires 4009-9801 External Battery
2081-9274	10 Ah			For Cabinet Infount	2081-9827	25 Ah	Cabinet (UL listed only)

TrueAlarm Smoke Detection

TrueAlarm Addressable Detection. IDNet addressable device compatibility includes Simplex TrueAlarm photoelectric smoke and temperature sensors. The 4008 fire alarm control panel provides a subset of the complete analog TrueAlarm features. TrueAlarm sensors appear to the panel essentially as addressable detectors and that term is used for 4008 documentation.

Approximately every four seconds the addressable smoke detectors transmit an output value based on their smoke chamber condition. The panel CPU internally maintains a current value, peak value, and an average value for each detector's output. Status is determined by comparing the current value to its average value. Tracking this average value as a continuously shifting reference point filters out environmental factors that cause shifts in sensitivity.

Alarm Determination. Photoelectric detection sensitivity is 2.5%/ft obscuration. All detectors can be selected for a reduced sensitivity detection mode that satisfies the city of Boston requirements. Addressable heat detectors provide a fixed temperature alarm at 135° F (57° C) and may be individually selected to also provide rate-of-rise alarm of 15° F (8.3° C) per minute where applicable.


Diagnostics and Default Device Type

Status Monitoring. 4008 TrueAlarm operation provides the ability to automatically indicate when an addressable detector is dirty or excessively dirty. The NFPA 72[®] (*National Fire Alarm Code*[®]) requirement for a test of the sensitivity range of the detectors is fulfilled by the TrueAlarm ability to maintain the sensitivity level of each addressable detector.

Modular Addressable Detector/Base Combination.

Modular TrueAlarm addressable detectors use the same base which allows different detector head types (photoelectric smoke, or heat) to be easily interchanged to meet specific application requirements. This feature also allows intentional detector (sensor head) substitution during building construction. When conditions are temporarily dusty, instead of covering the smoke detectors (causing them to be disabled), heat detector heads may be installed without reprogramming the control panel. Although the control panel will indicate an incorrect detector type, the heat detector will operate at a default setting to provide heat detection for building protection at that location.

Keyboard Reference



Compatible Simplex Peripherals (see specifications on page 5 for notification appliances)

Detector Heads and Addressable Bases (refer to page 3 for 4008 detector/sensor terminology)

Model	Detector Head Type	Compatible Addressable Base	Data Sheet	
		4098-9792, Standard detector base		
4098-9714	Dhotoplostrio	4098-9789, Base for remote LED or relay	S4098-0019	
	Photoelectric Heat, 135° F (57° C)	4098-9791, Features of 4098-9789 and rer		
4098-9733		4098-9794, Sounder base	S4098-0028	
		4098-9793, IDNet Isolator base		S4098-0025
4098-9754	Photo and Heat	4098-9795, Dual address sounder base	NOTE: These bases require	S4098-0033
4090-9754		4098-9796, Dual address standard base	two addresses	34096-0033

Duct Detection

Model	Description	Data Sheet		
4098-9755	Addressable Duct Detector Housing with 4098-9714 detector, no relay control			
4098-9756	Addressable Duct Detector Housing with 4098-9714 detector, with remote relay control	S4098-0030		

Addressable Devices

Model and Description	Data Sheet	Model and Description	Data Sheet	Model and Description	Data Sheet
4090-9001 Supervised IAM	S4090-0001	4090-9101 CL B ZAM	S4090-0003	4090-9007 Signal IAM	S4090-0010
4090-9051 Supervised IAM	34090-0001	4090-9106 CL A ZAM	54090-0003	4099-9001, 4099-9002,	
4090-9002 Relay IAM	S4090-0002	4090-9116 IDNet Isolator	S4090-0005	& 4099-9003 Manual Stations	S4099-0001

Compatible System Expansion Panels

Model	Туре	Description	Data Sheet
4003 Series	Voice Control Panel	Provides a remote voice control panel with on-board NACs, internal microphone, and remote microphone input	S4003-0001
4009 Series	Remote NAC Extender	Provides remote NACs; includes power supply and battery charger; 4 extenders max/NAC; 4008 uses NAC output to provide control	S4009-0002

Note: Contact your local Simplex Product Supplier for additional compatible peripherals.

Remote Annunciator Options


The 4008 supports up to four annunciator options including:

- Door Mounted 24 LED Annunciator
- 4610-9111 Remote LED/Switch Annunciators
- 4606-9101 Remote LCD Annunciators

Annunciators communicate at a rate of 9600 baud with power supplied by separate wiring.

4610-9111 LED Annunciator Features:

- 16 LEDs with programmable functions and dedicated LEDs for Alarm Silenced, Lost Communications, Trouble, and Power-on
- Keyswitch access controlled switches for Acknowledge, Alarm Silence, Reset, and Lamp Test
- Local tone-alert



4610-9111 LED/Switch Annunciator

4606-9101 LCD Annunciator Features:

- LCD readout with two lines of 40 characters each and LED backlighting
- Wide viewing angle, super-twist design
- · Keyswitch access controlled

Control switches and status LEDs for:

- Alarm, supervisory, or trouble acknowledge
- Alarm silence and System Reset

Three programmable LED indicators:

- Two LEDs are selectable as red or yellow
- One LED is selectable as green or yellow
- With provisions for custom labeling



4606-9101 LCD Annunciator

Specifications (Refer to Installation Instructions 579-716 for additional information)

	Input Voltage	120 VAC, 60 Hz; 220/230/240 VAC, 50/60 Hz, auto-select				
AC Input	Input Current, Standard	2 A maximum @ 120 VAC input; 1.5 A maximum @ 240 VAC input				
	Input Current with Expansion Power Supply	4 A maximum @ 120 VAC input; 3 A maximum @ 240 VAC input				
Power Supply O	utput	3 A maximum @ 24 VDC in alarm				
Battery Charger		Temperature compensated charger is rated for up to 25 Ah per UL 864; up to 12.7 Ah per ULC-S527				
Notification Ap	opliance Circuits (NACs) (N	NOTE: Total DC current = 3 A maximum per power supply)				
General Rating		2 A maximum @ 24 VDC, per NAC; available as Class A or Class B; Class B end-of-line resistor = 10 k Ω , 1/2 W; Model 4081-9008 (P/N 733-894)				
Strobe synchron	ation Rating = 2 A per NAC ization is UL listed across all Cs for these 4906 Series	Simplex 4901 Series (horns) and the following 4906 Series Multi-Candela: strobes horn/strobes, and speaker/strobes (see data sheets S4906-0001, S4906-0002, & S4906-0003)				
appliances		4906-9101 4906-9103 4906-9127 4906-9129 4906-9151 4906-915 4906-9102 4906-9104 4906-9128 4906-9130 4906-9153				
NOTE: Maximur supply or expans per power suppl	DC Rating = 1.5 A per NAC m strobe load on main power sion power supply is 1.35 A y (2.7 A total); remainder of ting is available for other	All other UL Listed Notification Appliances; use associated external synchronization modules where required				
Standard Circ	uit Ratings (NOTE: Total D	C current = 3 A maximum per power supply)				
Auxiliary Power	Output	500 mA maximum @ 24 VDC				
Standard Auxilia	ry Relay Outputs Relay 1 Relay 2	Programmable operation Contacts rated 2 A @ 30 VDC, 0.35 power factor; jumper selectable as N.O. or N.C.				
Wiring Connecti	•	Terminals rated for 18 AWG to 12 AWG (0.82 mm ² to 3.31 mm ²)				
IDNet Commu						
Quantity		Up to 200 addressable devices (see list on page 4)				
Suppression		For wiring external to building, use Overvoltage Protector 2081-9044 at each end of the connection; refer to data sheet S2081-0016 for details				
Wire Size		18 AWG (0.82 mm ²)				
	Inshielded twisted pair (UTP)	Acceptable for most applications; not for use with wiring in conduit with either NAC or AC power wiring (or similar)				
Wire Types	Shielded twisted pair (STP)	Shielded wire may provide protection from unexpected sources of interference and may be required for some applications; review system with your local Simplex product supplier				
	ontrol Panel to Farthest	Up to 4000 feet (1219 m) with 125 devices; 32 Ω				
Device		Up to 2500 feet (762 m) with 200 devices; 51 Ω				
Total Wire Lengi Class B Wiring	th Allowed With "T" Taps for	Up to 10,000 ft (3 km)				
Total Capacitan	ce Allowed	0.6 μF (600 nF)				
Annunciator C	ommunications					
Quantity Suppor		Up to four annunciator modules per panel (see page 4 for details)				
Wiring Size and		See description for IDNet wiring above				
Wiring Distances	Bus-Style Wiring	Up to 4000 ft (1219 m); 0.58 μF (580 nF) maximum capacitance; 35 Ω max.				
	"T-Tap" Wiring	Up to 10,000 ft (3048 m) total wiring; up to 2500 ft (762 m) to farthest device				
Line Matching R	esistor Bus-Style Wiring "T-Tap" Wiring	Connect one at panel and one at end of line 100 Ω , 1/2 W; 4081-9011; Connect one at panel and one at farthest device (part number 733-974)				
Suppression	1 Tap Willing	Use 2081-9044 Overvoltage Protectors where wiring leaves and enters a building (refer to data sheet S2081-0016)				
Option Module	Ratings	1.5.5. 15 data 5.150. 5255. 5510)				
Expansion Rela		2 A @ 30 VDC, 0.35 power factor; jumper selectable as N.O. or N.C.				
Module 4008-98	·	Terminals rated for 18 AWG to 12 AWG (0.82 mm² to 3.31 mm²)				
Environmenta		1				
Operating Temp		32° to 120°F (0° to 49° C)				
Operating Humi	_	Up to 93% RH, non-condensing @ 100.4° F (38° C) maximum				
, -		, , ,				

Supervisory and Alarm Currents

Model	Module	Supervisory	Alarm
4008-9101	Standard fire alarm control panel with 50 IDNet devices	175 mA	200 mA
4008-9121	Control panel with 24 LED Annunciator	193 mA + 1 mA per IDNet device	250 mA+ 1 mA per IDNet device
4008-9801	Expansion Power Supply	50 mA	60 mA
4008-9802	Expansion Relay Module	10 mA per energized relay	10 mA per energized relay
4008-9805	City Circuit Module with disconnect switch	30 mA	60 mA
4008-9806	City Circuit Module without disconnect switch	30 mA	60 mA
4606-9101	Remote LCD Annunciator (see data sheet S4606-0001)	100 mA	150 mA
4610-9111	Remote LED/Switch Annunciator (see data sheet S4610-0001)	40 mA	70 mA (all LEDs and tone-alert on)

** Current Calculation Information:

- 1. To determine total supervisory current, add currents of modules in panel to base system value and all auxiliary loads.
- 2. To determine total alarm current, add currents of modules in panel to base system alarm current **and** add all panel NAC loads **and** all auxiliary loads.

Addressable Device Information

The following addressable device types and hardware point types are provided. A combination of autoprogram, and either front panel or PC programming allows the operation to be selected per application.

Available Fire Detection Device Types

Device	Description	Options		
Photoelectric Addressable	TrueAlarm operation with	Sounder base (selectable for single station operation)	With communications isolator	
Detector	sensitivity = 2.5%/ft	With relay output	Selectable for all detectors to be at city of Boston sensitivity of 3.7%/ft	
Heat Detector	Fixed temperature thermal detection at 135° F (57.2° C)	Sounder base (selectable for single station operation)	With communications isolator	
Tieat Detector		With relay output	Individually selectable to add rate-of-rise heat detection of 15° F/minute (8.3° C/minute)	

Addressable Hardware Point Types

Function Type	Description	Function Type	Description
FIRE	Fire monitor device	WSO	Combination waterflow and water supervisory device
WATER	Waterflow monitor device	SUPV	Supervisory monitor
HEAT	Heat detector device	UTIL	Supervised utility monitor
DUCT	Duct detector device	TROUBLE	Trouble monitor
PULL	Manual (pull) station device	VSMOKE	Verified fire alarm; an alarm level causes the alarm verification cycle to start
SMOKE	Smoke detector device	STYLEC	Style C fire monitor
SO	Sprinkler Supervisory	LATSUPV	Latching supervisory monitor (supervisory latches until system is reset)

Relay Operation Modes

The following relay operations are selectable from either the front panel or the PC programmer.

Common Fire Alarm Operations

Function Type	Relay Activates Upon	Relay Deactivates Upon		
SRELAY	General Alarm	Silence		
RRELAY	General Alarm	Reset		
SUPV	Supervisory condition	Clear		
TRBL	Trouble condition	Acknowledged		


Special Functions

Function Type	Description				
UTILITY	Utility input in the same alarm group activates				
PRIMARY	General alarm; relay is tied to Primary Elevator Recall contacts				
ALTERN	General alarm; relay is tied to Alternate Elevator Recall contacts				
DRESET	Relay provides 24 VDC power to 4-wire addressable detectors; relay turns off for 5 seconds on System Reset				
DHOLDER	Relay provides 24 VDC to larger door holder relay with separate power source; relay activates on general alarm to remove power to door holder relay and close doors				


Additional Programming Feature Details

Function	Details										
Custom labels	Up to 20 characters per point; a built-in message library provides for commonly used words for easy front panel programming										
Message Library	For front panel label creation convenience, the following words can be selected as part of a custom label (_designates a built-in space; typing the first letter of a word/number will select the closest word in alphabetical/numerical sequence)										
	North South East West Front	Center rear 5th Flr_1 Flr_2	Flr_3 Flr_4 Flr_5 RM_	Basement Floor Garage Hallway HVAC_Room Kitchen	Lobby Office Patient upper lower	main first 2nd 3rd 4th	Boiler_RM Classroom Closet_ Corridor Elect_RM	Elevator Entrance Restroom Room Stairway	Storeroom Wing Zone		
History logs	Three separate logs: Alarm (100 entries), Supervisory (100 entries), and Trouble (300 entries); logs can be queried separately, or as a combined log; logs can be downloaded for printing or archiving using the RS-232 service port										
Autoprogram	Automatically scans system for installed option modules and configures panel programming accordingly; modes are available to detect new modules only, recreate default programming and then add all modules found; Scans of addressable loop adds addressable devices, displays total added; checks for duplicate addresses and identifies errors										
Alarm Groups	Up to 99 alarm groups are available, any point may be in up to 3 alarm groups; this allows NAC and relay operation to be associated with inputs according to local response requirements										
WALKTEST	Allows one person to perform system testing; alarm or trouble tests are followed by automatic reset; the alarm zone is sounded out by associated audible notification or the response is silently logged into the Alarm log										
Manual Control	Allows selection of individual relays or NACs for system testing										
Passcode Protection (4-digit number)	Level 1 = Acknowledge, Silence, System Reset, View logs, View point information, and Lamp Test Level 2 = All Level 1 + Set Time/Date, Point Control, Enable/Disable points Level 3 = All Level 2 + Clear logs, Clear verification tallies, Custom label editing, and WALKTEST Level 4 = All Level 3 + Programming, Upload/Download; this is the Service access level										

Installation and Module Placement Reference



Door LED Annunciator Details



Tyco, Simplex, the Simplex logo, TrueAlarm, IDNet, WALKTEST, and SmartSync are trademarks of Tyco International Services AG or its affiliates in the U.S. and/or other countries. NFPA 72 and National Fire Alarm Code are registered trademarks of the National Fire Protection Association (NFPA).

